





LT50/60
Mechanical Accessories

Miscellaneous

Dimensions (mm)	Cat. Number	Description
	4000551 (each)	LT50 Motor Mounting Screws- Flat Head, Self Tapping Tri lobe 5mm Dia. (13mm Deep) - Used with brackets Cat. No. 6070515 and 6070516 When using screws or brackets other than by SOMFY, please contact our sales department for complete motor mounting specifications.
	4000555	LT50 RH Motor Mounting Screws - Flat Head, Self Tapping Tri lobe 4mm Dia. (9mm Deep)
	4000556	ILT RH Motor Mounting Screws - Flat Head, Self Tapping Tri Lobe 5mm Dia. (12mm Deep)
	4350002	Cotter Pin - 3.5mm x 45mm
	4350026	Spring Ring - Used with Brackets and Motors rated up to 80 Nm maximum - Stainless steel spring type
	4350027	Locking Spring Ring - Must be used with all brackets in combination with the 6100R2 motor or installations where flexing of the tube is abnormally high - Used with brackets and motors rated up to 100 Nm - Spring type stainless steel - Locking screw must be secured to prevent the motor from disengaging from the universal bracket
	4350028	Pull-off Tool for Spring Ring - Black finished steel
	4350029	Cord Setting Tool - Permits setting of the UP and Down positions when there is limited access to the motor's limit switch buttons - Instructions included
	4350030	Spring Ring with Loop - Used with Brackets and Motors rated up to 80 Nm maximum - Allows for easy hand removal from the bracket - Spring type stainless steel
	4350031	Limit Switch Button Extensions - Consists of 2 white and 2 yellow extensions